

PART NAME	BLDC CABLE EXTENSION
PART NUMBER	4634141000277

Note: Multiple extension cable can be connected for longer lengths

Connects to BLDC Motor

Connects to Driver

MOTOR PHASE	PIN #
U	3
V	2
W	1

HALL SENSOR	PIN #
5V	1
N/A	2
HB	3
HA	4
GND	5
HC	6

